



merit industries, inc.

FIELD BULLETIN

Date: 2-27-97

- Issue:** Megatouch XL games purchased with the R0D program CD may crash after the first credit is entered.
- Games affected:** Megatouch XL games purchased with the R0D program CD.
- Symptoms:** Game crashes after first credit is entered.
- Cause:** This revision of the program was not set to clear the NV RAM on first power up.
- Solution:** Do a 2-button memory clear to clear the NV RAM. To perform a 2-button clear: Turn off the game. Press and firmly hold the SETUP and CALIBRATE buttons (located in the coin mech section of the game) while turning the power on. Wait for the "2 BUTTON CLEAR DETECTED" message to appear on the screen before releasing the buttons (this may take up to 40 seconds)