

Tech Notes

<http://www.meritind.com>



merit industries, inc.

Date: 08-07-00

Re: Using a CD-ROM to Update a MAXX™ game

When performing a CD update, it is recommended that you use a CD-ROM drive of at least 8X or better that is capable of operating on an angled surface, as you may not always have a level surface on which to place the drive.

You must also configure your CD-ROM drive as the Master Drive in order to perform this upgrade. See Figure 1 below for typical master drive jumper location.




Figure 1 - Typical Location of Master/Slave Jumpers