

**ATTENTION:**

OBSERVE PRECAUTIONS FOR HANDLING ELECTROSTATIC DEVICES

**Removal/Installation of Hard Drive -  
FORCE Radion Countertop/Fun Zone JR.**

**Hard Drive Removal**

1. Turn off and unplug the game.
2. Unlock and open/remove the side doors and the rear door.
3. Locate the hard drive and remove the 2 screws securing the hard drive mounting bracket to the game (see Figure 2), then remove the hard drive assembly until you're able to disconnect the hard drive power connector and the motherboard ribbon cable.
4. Remove the 4 screws and shoulder washers fastening the hard drive to the mounting plate.

**Hard Drive Installation**

1. Fasten the new hard drive to the mounting plate with the 4 screws and shoulder washers.
2. Connect the power connector and the hard drive ribbon cable to the hard drive, then replace the hard drive assembly in the game and fasten it with the 2 screws.
3. Close/replace and lock the rear door and the side doors.
4. Plug in and turn on the game.

**Troubleshooting Information - Removal/Installation of Hard Drive -  
FORCE Radion Countertop/Fun Zone JR.**

Megatouch FORCE Technical Reference Manual




FIGURE 1 – MOTHERBOARD REMOVAL –  
LOCATION OF SCREWS SECURING MOTHERBOARD TO MOUNTING FRAME




FIGURE 2 - HARD DRIVE REMOVAL