

## Rx Optional Marquee Installation Instructions

### **CAUTION!**

**WHILE THE RX MARQUEE IS OPTIONAL, DUE TO THE STRONG ADHESIVE USED TO SECURE IT, ONCE IT IS INSTALLED, IT IS NOT MEANT TO BE REMOVED.**

*The marquee should never be used as a handle when servicing the game, as it was not designed for this purpose. When used inappropriately in this fashion, the marquee could break, causing the bezel to slam down and thereby damaging the system. The monitor bezel should always be opened by using the handle on the rear of the coin/bill acceptor.*

### **Before you begin installation:**

Line up the marquee as shown in Figure 1. The right side of the marquee (looking from the front) should be even with the front of the plastic on the coin/bill acceptor, and the front base of the marquee should be even across the front of the monitor bezel. This step is just so you can see how the marquee should fit without using any adhesive. You may also find it helpful to use a pencil and draw a very light line on the top of the bezel to mark the rear of the marquee. You can then follow this guideline when you permanently secure the marquee to the bezel.



FIGURE 1 – RX MARQUEE PLACEMENT (SIDE VIEW)

### **Marquee Installation:**

1. Remove the two strips covering the two pieces of tape on the bottom of the marquee.
2. Carefully line up the marquee on top of the bezel. Follow any guidelines you have drawn for yourself, or refer to Figure 1 for placement.
3. Press down on the base of the marquee to ensure that the adhesive has fully bonded with the bezel.