







## AMI Entertainment Network

### Troubleshooting Guide for *Megatouch MAXX games*

---

PROBLEM	CORRECTIVE ACTION
<ul style="list-style-type: none"><li>• <b>game will not download CD</b></li></ul>	<ul style="list-style-type: none"><li>• Make sure the CD is installed correctly, with the logo facing up.</li><li>• Check for scratches or a defective disc.</li><li>• Try a different set of CDs.</li><li>• If you're downloading a CD set, make sure each disc is of the same revision.</li></ul>