

ATTENTION:

OBSERVE PRECAUTIONS FOR HANDLING ELECTROSTATIC DEVICES

Removal/Installation of Major Assemblies - eVo/eVo Walleto/Elite Edge Ion

Power Supply Removal

1. Turn off and unplug the game.
2. Unlock and open the CPU section.
3. Unplug the IEC connector from the power supply. See Figure 1.
4. Disconnect the wire connector nearest to the power supply.
5. Remove the 2 screws fastening the power supply and mounting bracket to the game. See Figure 2.
6. Remove the power supply.

Power Supply Installation

1. Install the new power supply and bracket in the game and fasten them with the 2 screws that were used to fasten the old power supply and bracket. See Figure 2.
2. Connect the power supply wire connection.
3. Reconnect the IEC connector to the power supply. See Figure 1.
4. Close and lock the CPU section.
5. Plug in and turn on the game.




FIGURE 1 - OVERVIEW OF HARD DRIVE



FIGURE 2 - POWER SUPPLY MOUNTING
SCREWS (2 PLACES)