



merit industries, inc.

# TECH NOTES

<http://www.meritind.com>

Date: 04-17-01

## Re: Linking Megatouch MAXX™ Games

Megatouch MAXX™ games that are connected using the Mega-Link® system must have the same level of software for proper operation. The Double Diamond and Diamond 2 releases are designed to detect other levels of software in linked games. If a different level is detected, you will receive a screen that says, "MEGALINK MISMATCH CALL ATTENDANT." This screen will be displayed approximately 5 minutes after you turn the games on. To clear the screen and continue playing the games, you must turn the power off, unlink the games, and turn the power back on again. If you want to link these games you must upgrade all games to the same software level. This software can be obtained through your distributor.



SCREEN DISPLAY AFTER LINKING DOUBLE DIAMOND OR DIAMOND 2 GAMES WITH ANOTHER VERSION OF SOFTWARE